

// CONQUEST HD



We make it visible.



DISCOVER THE SMALLEST DETAILS.
EXPERIENCE THE GREATEST MOMENTS.
THIS IS THE MOMENT WE WORK FOR.

Nature never stops and neither does ZEISS. This becomes particularly clear with the CONQUEST HD. A revolution in design, ergonomics and optics. The perfect "Made in Germany" all-rounder combines traditional ZEISS quality with state-of-the-art technology. All this makes the CONQUEST HD binoculars the uncompromising entry into the premium class of ZEISS.

Thanks to the new HD lens system, the CONQUEST HD displays its strengths with optimal image quality and colour fidelity. Such as the exceptionally large field of view for unforgettable experiences or its LotuTec® coating for clear visibility in any weather condition, and easy cleaning. In addition, the ZEISS T* multi-layer coating on the CONQUEST HD with a light transmission of over 90%, allows for observation well into twilight.

Extremely lightweight, it is all the more striking that the ZEISS CONQUEST HD is such a compact and robust companion. It is the culmination of its distinctive design, which combines perfect ergonomics with extremely easy operation. Thanks to the specially shaped grips and large focussing wheel, it is very easy to use and can be focussed precisely even while wearing gloves.

ZEISS CONQUEST® HD.
BOTH OPTICS AND PERFORMANCE
ARE GUARANTEED TO IMPRESS.



// CONQUEST
ZEISS. PIONEER SINCE 1846.

- Razor-sharp detail and natural colour reproduction: HD lens system
- Compact size and a lightweight, modern design: Perfect ergonomics
- Relaxed observation and an impressive overview: Extra-wide field of view
- Clear visibility in any weather and easy cleaning: LotuTec® coating
- Observe the smallest details from up close: Outstanding close focus performance
- Proven quality and a chic design: "Made in Germany"

ZEISS CONQUEST HD. THE MODERN OBSERVATION OPTICS.



8 x 32 and 10 x 32

The new CONQUEST HD 8 x 32 is compact, lightweight and ideal for travel, nature and leisure activities. The 8x magnification and the wide field of view guarantee particularly comfortable observation. The 10 x 32 provides perfect observation at long range in daylight. It offers a wealth of detail even at long distances. Both are also hugely impressive at close quarters with an optimum value of 1.5 m.



8 x 42 and 10 x 42

As a robust companion for twilight use, designed to offer great versatility, the 8 x 42 with its 8 x magnification gives a stable image in all situations. The 10 x 42, on the other hand, boasts the largest field of view in its class. It provides highly detailed images of the natural world even at long range and enables long periods of effortless observation.



8 x 56, 10 x 56 and 15 x 56 **NEW**

All 56 mm models are ideal companions for viewing under the most challenging light conditions. They are very impressive with the widest fields of view, maximum brightness and brilliant high-contrast images. The 8 x 56 offers the largest eye relief and image stability for relaxed viewing into the deepest twilight, while the 10 x 56 is ideal for seeing details even at long distances. The 15 x 56 is used for extremely long distances. Discover nature's smallest secrets and optimise your visual experience with the 1/4" tripod adapter included in delivery.

TECHNICAL DATA.

	8 x 32	10 x 32	8 x 42	10 x 42	8 x 56	10 x 56	15 x 56
Magnification	8 x	10 x	8 x	10 x	8 x	10 x	15 x
Lens diameter	32 mm	32 mm	42 mm	42 mm	56 mm	56 mm	56 mm
Exit pupil diameter	4.0 mm	3.2 mm	5.3 mm	4.2 mm	7.0 mm	5.6 mm	3.7 mm
Twilight factor	16.0	17.9	18.3	20.5	21.2	23.7	29.0
Field of view at 1000 m	140 m	118 m	128 m	115 m	125 m	115 m	80 m
Subjective viewing angle	64°	68°	59°	66°	57°	66°	69°
Close focus	1.5 m	1.5 m	2 m	2 m	3.5 m	3.5 m	3.5 m
Diopter adjustment range	+/-4 dpt	+/-4 dpt	+/-4 dpt	+/-4 dpt	+/-4 dpt	+/-4 dpt	+/-4 dpt
Eye relief	16 mm	16 mm	18 mm	18 mm	18 mm	18 mm	18 mm
Pupil distance	54-74	54-74	54-74	54-74	57-74	57-74	57-74
Lens type	HD	HD	HD	HD	HD	HD	HD
Prism system	Schmidt-Pechan	Schmidt-Pechan	Schmidt-Pechan	Schmidt-Pechan	Abbe-König	Abbe-König	Abbe-König
Coating	LotuTec/T*	LotuTec/T*	LotuTec/T*	LotuTec/T*	LotuTec/T*	LotuTec/T*	LotuTec/T*
Nitrogen filling	Yes	Yes	Yes	Yes	Yes	Yes	Yes
Water resistance	400 mbar	400 mbar	400 mbar	400 mbar	400 mbar	400 mbar	400 mbar
Functional temperature range	-20/+63 °C	-20/+63 °C	-20/+63 °C	-20/+63 °C	-20/+63 °C	-20/+63 °C	-20/+63 °C
Height	132 mm	132 mm	150 mm	150 mm	210 mm	210 mm	210 mm
Width at an eye width of 65 mm	118 mm	118 mm	120 mm	120 mm	145 mm	145 mm	145 mm
Weight	630 g	630 g	795 g	795 g	1265 g	1275 g	1295 g
Order number	52 32 11	52 32 12	52 42 11	52 42 12	52 56 31	52 56 32	52 56 33

T* = ZEISS T* multi-layer coating

Technical notes: The design and scope of delivery related to technical developments may be subject to change. No liability for mistakes or printing errors.



THE MOMENT WHEN YOU ARE
CLOSER TO NATURE THAN EVER BEFORE.
THIS IS THE MOMENT WE WORK FOR.

Learn more about our other products:

www.zeiss.com/sports-optics



www.facebook.com/ZEISSBirding