



Depth of Field Tables in Feet

for

ARRI/ZEISS Master Anamorphic Lenses

circle of confusion: 0.030 mm

Master Anamorphic 2x	MA 28/T1.9	T*XP
Master Anamorphic 2x	MA 35/T1.9	T*XP
Master Anamorphic 2x	MA 40/T1.9	T*XP
Master Anamorphic 2x	MA 50/T1.9	T*XP
Master Anamorphic 2x	MA 60/T1.9	T*XP
Master Anamorphic 2x	MA 75/T1.9	T*XP
Master Anamorphic 2x	MA 100/T1.9	T*XP
Master Anamorphic 2x	MA 135/T1.9	T*XP
Master Anamorphic 2x	MA 180/T2.8	T*XP

Depth of field tables

ARRI/ZEISS Master Anamorphic 2x MA 28/T1.9 T*XP

circle of confusion: 0.030 mm

Engraving	T-Stop					
	1.9		2		2.8	
ft	from	to	from	to	from	to
hyperfocal distance	44.97'		41.92'		29.67'	
INF	44.97'	INF	41.92'	INF	29.67'	INF
300'	39.05'	INF	36.72'	INF	26.93'	INF
150'	34.56'	INF	32.72'	INF	24.72'	INF
100'	31.00'	INF	29.51'	INF	22.84'	INF
70'	27.37'	INF	26.20'	INF	20.81'	INF
50'	23.67'	INF	22.80'	INF	18.60'	INF
40'	21.17'	361.23'	20.47'	873.21'	17.03'	INF
30'	18.00'	89.94'	17.49'	105.30'	14.92'	INF
25'	16.08'	56.18'	15.67'	61.81'	13.57'	158.45'
22'	14.78'	42.98'	14.44'	46.20'	12.64'	84.87'
20'	13.85'	35.95'	13.55'	38.17'	11.95'	61.19'
18'	12.87'	29.95'	12.60'	31.48'	11.21'	45.63'
16'	11.81'	24.79'	11.59'	25.82'	10.40'	34.62'
14'	10.69'	20.29'	10.51'	20.98'	9.52'	26.43'
13'	10.10'	18.25'	9.93'	18.80'	9.05'	23.07'
12'	9.48'	16.33'	9.34'	16.78'	8.56'	20.09'
11'	8.85'	14.53'	8.73'	14.88'	8.04'	17.43'
10'	8.19'	12.83'	8.09'	13.10'	7.49'	15.04'
9' 6"	7.85'	12.02'	7.76'	12.26'	7.21'	13.93'
9'	7.51'	11.23'	7.42'	11.44'	6.92'	12.88'
8' 6"	7.16'	10.46'	7.08'	10.64'	6.62'	11.88'
8'	6.80'	9.71'	6.73'	9.87'	6.31'	10.92'
7' 6"	6.44'	8.98'	6.37'	9.11'	6.00'	10.01'
7'	6.07'	8.27'	6.01'	8.39'	5.68'	9.13'
6' 6"	5.69'	7.58'	5.64'	7.68'	5.34'	8.30'
6'	5.30'	6.91'	5.26'	6.99'	5.00'	7.50'
5' 9"	5.11'	6.58'	5.07'	6.65'	4.83'	7.11'
5' 6"	4.91'	6.25'	4.87'	6.32'	4.65'	6.73'
5' 3"	4.71'	5.93'	4.67'	5.99'	4.47'	6.36'
5'	4.51'	5.61'	4.48'	5.67'	4.29'	6.00'
4' 9"	4.30'	5.30'	4.27'	5.35'	4.10'	5.64'
4' 6"	4.10'	4.99'	4.07'	5.03'	3.92'	5.29'
4' 3"	3.89'	4.68'	3.87'	4.72'	3.73'	4.95'
4'	3.68'	4.38'	3.66'	4.41'	3.53'	4.61'
3' 9"	3.47'	4.08'	3.45'	4.11'	3.34'	4.28'
3' 6"	3.25'	3.79'	3.24'	3.81'	3.14'	3.96'
3' 3"	3.04'	3.50'	3.02'	3.52'	2.94'	3.64'
3'	2.82'	3.21'	2.81'	3.22'	2.73'	3.33'
2' 9"	2.60'	2.92'	2.59'	2.94'	2.52'	3.02'
2' 6"	2.37'	2.64'	2.36'	2.65'	2.31'	2.72'
2' 3"	2.15'	2.36'	2.14'	2.37'	2.10'	2.43'

Depth of field tables

ARRI/ZEISS Master Anamorphic 2x MA 28/T1.9 T*XP

circle of confusion: 0.030 mm

Engraving	T-Stop					
	4		5.6		8	
ft	from	to	from	to	from	to
hyperfocal distance	21.00'		14.88'		10.55'	
INF	21.00'	INF	14.88'	INF	10.55'	INF
300'	19.56'	INF	14.10'	INF	10.11'	INF
150'	18.36'	INF	13.47'	INF	9.78'	INF
100'	17.31'	INF	12.89'	INF	9.47'	INF
70'	16.12'	INF	12.22'	INF	9.11'	INF
50'	14.76'	INF	11.43'	INF	8.66'	INF
40'	13.75'	INF	10.81'	INF	8.30'	INF
30'	12.35'	INF	9.93'	INF	7.77'	INF
25'	11.41'	INF	9.31'	INF	7.39'	INF
22'	10.74'	INF	8.87'	INF	7.11'	INF
20'	10.25'	416.49'	8.52'	INF	6.89'	INF
18'	9.70'	125.30'	8.14'	INF	6.64'	INF
16'	9.09'	66.86'	7.71'	INF	6.35'	INF
14'	8.41'	41.80'	7.22'	235.43'	6.01'	INF
13'	8.04'	33.96'	6.94'	102.29'	5.82'	INF
12'	7.65'	27.87'	6.65'	61.63'	5.61'	INF
11'	7.23'	22.99'	6.33'	41.93'	5.38'	INF
10'	6.79'	19.00'	5.99'	30.31'	5.14'	190.68'
9' 6"	6.55'	17.27'	5.81'	26.11'	5.00'	94.75'
9'	6.31'	15.68'	5.62'	22.64'	4.86'	60.78'
8' 6"	6.06'	14.22'	5.42'	19.70'	4.71'	43.39'
8'	5.81'	12.87'	5.21'	17.20'	4.56'	32.82'
7' 6"	5.54'	11.61'	5.00'	15.03'	4.39'	25.73'
7'	5.26'	10.45'	4.77'	13.14'	4.22'	20.63'
6' 6"	4.98'	9.37'	4.54'	11.47'	4.03'	16.79'
6'	4.68'	8.36'	4.29'	9.99'	3.83'	13.79'
5' 9"	4.53'	7.88'	4.16'	9.31'	3.73'	12.53'
5' 6"	4.37'	7.42'	4.03'	8.67'	3.63'	11.39'
5' 3"	4.21'	6.97'	3.89'	8.06'	3.52'	10.36'
5'	4.05'	6.53'	3.75'	7.48'	3.40'	9.42'
4' 9"	3.89'	6.11'	3.61'	6.93'	3.29'	8.57'
4' 6"	3.72'	5.70'	3.47'	6.41'	3.17'	7.78'
4' 3"	3.55'	5.31'	3.32'	5.91'	3.04'	7.06'
4'	3.37'	4.92'	3.16'	5.44'	2.91'	6.39'
3' 9"	3.19'	4.55'	3.01'	4.98'	2.78'	5.77'
3' 6"	3.01'	4.18'	2.85'	4.55'	2.64'	5.19'
3' 3"	2.82'	3.83'	2.68'	4.13'	2.50'	4.66'
3'	2.63'	3.48'	2.51'	3.73'	2.35'	4.16'
2' 9"	2.44'	3.15'	2.33'	3.35'	2.19'	3.69'
2' 6"	2.24'	2.83'	2.15'	2.99'	2.03'	3.25'
2' 3"	2.04'	2.51'	1.96'	2.63'	1.87'	2.84'

Depth of field tables

ARRI/ZEISS Master Anamorphic 2x MA 28/T1.9 T*XP

circle of confusion: 0.030 mm

Engraving	T-Stop					
	11		16		22	
ft	from	to	from	to	from	to
hyperfocal distance	7.49'		5.32'		3.79'	
INF	7.49'	INF	5.32'	INF	3.79'	INF
300'	7.22'	INF	5.14'	INF	3.65'	INF
150'	7.05'	INF	5.06'	INF	3.61'	INF
100'	6.89'	INF	4.97'	INF	3.57'	INF
70'	6.70'	INF	4.87'	INF	3.52'	INF
50'	6.45'	INF	4.74'	INF	3.45'	INF
40'	6.25'	INF	4.63'	INF	3.39'	INF
30'	5.95'	INF	4.46'	INF	3.30'	INF
25'	5.72'	INF	4.34'	INF	3.23'	INF
22'	5.55'	INF	4.24'	INF	3.18'	INF
20'	5.42'	INF	4.16'	INF	3.13'	INF
18'	5.26'	INF	4.07'	INF	3.08'	INF
16'	5.08'	INF	3.96'	INF	3.02'	INF
14'	4.86'	INF	3.83'	INF	2.94'	INF
13'	4.73'	INF	3.75'	INF	2.89'	INF
12'	4.60'	INF	3.66'	INF	2.84'	INF
11'	4.44'	INF	3.56'	INF	2.78'	INF
10'	4.27'	INF	3.45'	INF	2.72'	INF
9' 6"	4.18'	INF	3.39'	INF	2.68'	INF
9'	4.08'	INF	3.33'	INF	2.64'	INF
8' 6"	3.98'	INF	3.26'	INF	2.60'	INF
8'	3.87'	INF	3.18'	INF	2.55'	INF
7' 6"	3.75'	INF	3.10'	INF	2.50'	INF
7'	3.62'	106.51'	3.02'	INF	2.44'	INF
6' 6"	3.48'	48.74'	2.92'	INF	2.38'	INF
6'	3.34'	29.85'	2.82'	INF	2.31'	INF
5' 9"	3.26'	24.49'	2.76'	INF	2.27'	INF
5' 6"	3.18'	20.48'	2.70'	INF	2.23'	INF
5' 3"	3.09'	17.36'	2.64'	389.70'	2.19'	INF
5'	3.01'	14.87'	2.58'	81.58'	2.15'	INF
4' 9"	2.91'	12.84'	2.51'	43.53'	2.10'	INF
4' 6"	2.82'	11.14'	2.44'	28.68'	2.05'	INF
4' 3"	2.72'	9.71'	2.37'	20.76'	2.00'	INF
4'	2.62'	8.48'	2.29'	15.84'	1.95'	INF
3' 9"	2.51'	7.42'	2.21'	12.48'	1.89'	353.55'
3' 6"	2.40'	6.49'	2.12'	10.05'	1.82'	44.74'
3' 3"	2.28'	5.67'	2.03'	8.21'	1.75'	22.28'
3'	2.15'	4.94'	1.93'	6.76'	1.68'	14.05'
2' 9"	2.02'	4.29'	1.82'	5.59'	1.60'	9.78'
2' 6"	1.89'	3.71'	1.71'	4.63'	1.51'	7.17'
2' 3"	1.74'	3.18'	1.59'	3.83'	1.42'	5.40'

Depth of field tables

ARRI/ZEISS Master Anamorphic 2x MA 35/T1.9 T*XP

circle of confusion: 0.030 mm

Engraving	T-Stop					
	1.9		2		2.8	
ft	from	to	from	to	from	to
hyperfocal distance	68.83'		64.00'		45.29'	
INF	68.83'	INF	64.00'	INF	45.29'	INF
300'	55.92'	INF	52.69'	INF	39.28'	INF
150'	47.15'	INF	44.83'	INF	34.74'	INF
100'	40.76'	INF	39.01'	INF	31.14'	INF
70'	34.70'	INF	33.43'	INF	27.48'	INF
50'	28.97'	182.49'	28.08'	228.15'	23.76'	INF
40'	25.31'	95.35'	24.63'	106.47'	21.24'	341.64'
30'	20.91'	53.09'	20.44'	56.37'	18.06'	88.64'
25'	18.35'	39.20'	17.99'	40.95'	16.12'	55.66'
22'	16.69'	32.28'	16.39'	33.46'	14.82'	42.67'
20'	15.51'	28.15'	15.25'	29.04'	13.89'	35.73'
18'	14.28'	24.33'	14.06'	25.00'	12.90'	29.80'
16'	13.00'	20.81'	12.81'	21.30'	11.84'	24.68'
14'	11.65'	17.55'	11.50'	17.89'	10.71'	20.21'
13'	10.95'	16.00'	10.82'	16.28'	10.12'	18.19'
12'	10.23'	14.51'	10.12'	14.74'	9.50'	16.28'
11'	9.50'	13.07'	9.40'	13.26'	8.86'	14.49'
10'	8.74'	11.68'	8.66'	11.83'	8.21'	12.80'
9' 6"	8.36'	11.00'	8.28'	11.14'	7.87'	11.99'
9'	7.97'	10.34'	7.90'	10.45'	7.52'	11.20'
8' 6"	7.58'	9.68'	7.51'	9.78'	7.17'	10.44'
8'	7.18'	9.04'	7.12'	9.13'	6.81'	9.69'
7' 6"	6.77'	8.40'	6.72'	8.48'	6.45'	8.97'
7'	6.36'	7.78'	6.32'	7.85'	6.07'	8.26'
6' 6"	5.95'	7.17'	5.91'	7.22'	5.70'	7.57'
6' 3"	5.74'	6.86'	5.70'	6.91'	5.50'	7.23'
6'	5.53'	6.56'	5.49'	6.61'	5.31'	6.90'
5' 9"	5.31'	6.26'	5.28'	6.31'	5.11'	6.57'
5' 6"	5.10'	5.97'	5.07'	6.01'	4.91'	6.24'
5' 3"	4.89'	5.67'	4.86'	5.71'	4.71'	5.92'
5'	4.67'	5.38'	4.65'	5.41'	4.51'	5.61'
4' 9"	4.45'	5.09'	4.43'	5.12'	4.31'	5.29'
4' 6"	4.23'	4.81'	4.21'	4.83'	4.10'	4.98'
4' 3"	4.01'	4.52'	3.99'	4.54'	3.89'	4.68'
4'	3.79'	4.24'	3.77'	4.26'	3.68'	4.38'
3' 9"	3.56'	3.96'	3.55'	3.98'	3.47'	4.08'
3' 6"	3.34'	3.68'	3.32'	3.70'	3.26'	3.78'
3' 3"	3.11'	3.41'	3.10'	3.42'	3.04'	3.49'
3'	2.88'	3.13'	2.87'	3.14'	2.82'	3.21'
2' 9"	2.65'	2.86'	2.64'	2.87'	2.60'	2.92'
2' 6"	2.42'	2.59'	2.41'	2.60'	2.38'	2.64'

Depth of field tables

ARRI/ZEISS Master Anamorphic 2x MA 35/T1.9 T*XP

circle of confusion: 0.030 mm

Engraving	T-Stop					
	4		5.6		8	
ft	from	to	from	to	from	to
hyperfocal distance	32.06'		22.70'		16.09'	
INF	32.06'	INF	22.70'	INF	16.09'	INF
300'	28.88'	INF	21.01'	INF	15.17'	INF
150'	26.35'	INF	19.64'	INF	14.45'	INF
100'	24.23'	INF	18.44'	INF	13.79'	INF
70'	21.96'	INF	17.10'	INF	13.02'	INF
50'	19.52'	INF	15.58'	INF	12.13'	INF
40'	17.79'	INF	14.46'	INF	11.44'	INF
30'	15.50'	465.67'	12.91'	INF	10.45'	INF
25'	14.05'	113.15'	11.90'	INF	9.77'	INF
22'	13.06'	69.87'	11.17'	707.89'	9.28'	INF
20'	12.33'	52.98'	10.64'	167.19'	8.91'	INF
18'	11.54'	40.90'	10.05'	86.47'	8.49'	INF
16'	10.69'	31.83'	9.39'	53.92'	8.02'	INF
14'	9.76'	24.77'	8.67'	36.34'	7.49'	107.17'
13'	9.26'	21.79'	8.28'	30.27'	7.20'	67.27'
12'	8.75'	19.11'	7.86'	25.33'	6.88'	46.90'
11'	8.20'	16.69'	7.42'	21.23'	6.54'	34.54'
10'	7.64'	14.48'	6.96'	17.78'	6.18'	26.24'
9' 6"	7.34'	13.45'	6.71'	16.25'	5.98'	23.04'
9'	7.04'	12.47'	6.46'	14.84'	5.78'	20.29'
8' 6"	6.73'	11.53'	6.20'	13.52'	5.57'	17.90'
8'	6.42'	10.62'	5.93'	12.29'	5.36'	15.80'
7' 6"	6.09'	9.76'	5.65'	11.14'	5.13'	13.95'
7'	5.76'	8.92'	5.37'	10.07'	4.89'	12.30'
6' 6"	5.42'	8.12'	5.07'	9.06'	4.64'	10.83'
6' 3"	5.24'	7.74'	4.92'	8.58'	4.52'	10.15'
6'	5.07'	7.36'	4.76'	8.11'	4.38'	9.50'
5' 9"	4.89'	6.98'	4.60'	7.66'	4.25'	8.89'
5' 6"	4.71'	6.62'	4.44'	7.22'	4.11'	8.30'
5' 3"	4.52'	6.26'	4.28'	6.80'	3.97'	7.74'
5'	4.34'	5.90'	4.11'	6.38'	3.83'	7.20'
4' 9"	4.15'	5.56'	3.94'	5.98'	3.68'	6.69'
4' 6"	3.96'	5.22'	3.77'	5.58'	3.53'	6.20'
4' 3"	3.76'	4.88'	3.59'	5.20'	3.38'	5.74'
4'	3.57'	4.55'	3.41'	4.83'	3.22'	5.29'
3' 9"	3.37'	4.23'	3.23'	4.47'	3.06'	4.86'
3' 6"	3.17'	3.92'	3.04'	4.12'	2.89'	4.44'
3' 3"	2.96'	3.60'	2.85'	3.77'	2.72'	4.04'
3'	2.75'	3.30'	2.66'	3.44'	2.54'	3.66'
2' 9"	2.54'	3.00'	2.46'	3.11'	2.36'	3.29'
2' 6"	2.33'	2.70'	2.26'	2.80'	2.18'	2.94'

Depth of field tables

ARRI/ZEISS Master Anamorphic 2x MA 35/T1.9 T*XP

circle of confusion: 0.030 mm

Engraving	T-Stop					
	11		16		22	
ft	from	to	from	to	from	to
hyperfocal distance	11.41'		8.10'		5.76'	
INF	11.41'	INF	8.10'	INF	5.76'	INF
300'	10.89'	INF	7.78'	INF	5.55'	INF
150'	10.51'	INF	7.59'	INF	5.45'	INF
100'	10.16'	INF	7.40'	INF	5.35'	INF
70'	9.74'	INF	7.18'	INF	5.23'	INF
50'	9.23'	INF	6.90'	INF	5.08'	INF
40'	8.83'	INF	6.67'	INF	4.96'	INF
30'	8.23'	INF	6.33'	INF	4.77'	INF
25'	7.80'	INF	6.07'	INF	4.62'	INF
22'	7.49'	INF	5.88'	INF	4.51'	INF
20'	7.24'	INF	5.73'	INF	4.42'	INF
18'	6.97'	INF	5.56'	INF	4.32'	INF
16'	6.65'	INF	5.35'	INF	4.20'	INF
14'	6.28'	INF	5.11'	INF	4.05'	INF
13'	6.07'	INF	4.97'	INF	3.96'	INF
12'	5.85'	INF	4.82'	INF	3.87'	INF
11'	5.60'	304.19'	4.66'	INF	3.76'	INF
10'	5.33'	80.19'	4.47'	INF	3.64'	INF
9' 6"	5.19'	56.22'	4.37'	INF	3.57'	INF
9'	5.04'	42.20'	4.26'	INF	3.50'	INF
8' 6"	4.88'	33.01'	4.15'	INF	3.42'	INF
8'	4.71'	26.51'	4.03'	635.13'	3.34'	INF
7' 6"	4.54'	21.67'	3.90'	99.72'	3.25'	INF
7'	4.35'	17.93'	3.76'	50.79'	3.15'	INF
6' 6"	4.15'	14.96'	3.61'	32.43'	3.05'	INF
6' 3"	4.05'	13.68'	3.54'	26.97'	3.00'	INF
6'	3.94'	12.53'	3.45'	22.81'	2.94'	INF
5' 9"	3.84'	11.48'	3.37'	19.54'	2.88'	INF
5' 6"	3.72'	10.51'	3.29'	16.89'	2.82'	118.72'
5' 3"	3.61'	9.63'	3.20'	14.71'	2.75'	57.95'
5'	3.49'	8.81'	3.10'	12.88'	2.68'	37.07'
4' 9"	3.37'	8.06'	3.01'	11.32'	2.61'	26.51'
4' 6"	3.24'	7.36'	2.91'	9.98'	2.53'	20.14'
4' 3"	3.11'	6.71'	2.80'	8.81'	2.45'	15.88'
4'	2.98'	6.10'	2.69'	7.79'	2.37'	12.82'
3' 9"	2.84'	5.53'	2.58'	6.88'	2.28'	10.53'
3' 6"	2.69'	5.00'	2.46'	6.08'	2.19'	8.74'
3' 3"	2.54'	4.50'	2.33'	5.35'	2.09'	7.31'
3'	2.39'	4.03'	2.20'	4.70'	1.99'	6.13'
2' 9"	2.23'	3.59'	2.07'	4.10'	1.88'	5.16'
2' 6"	2.06'	3.17'	1.93'	3.57'	1.76'	4.33'

Depth of field tables

ARRI/ZEISS Master Anamorphic 2x MA 40/T1.9 T*XP

circle of confusion: 0.030 mm

Engraving	T-Stop					
	1.9		2		2.8	
ft	from	to	from	to	from	to
hyperfocal distance	89.42'		83.29'		58.94'	
INF	89.42'	INF	83.29'	INF	58.94'	INF
300'	68.83'	INF	65.14'	INF	49.19'	INF
150'	56.00'	INF	53.53'	INF	42.27'	INF
100'	47.20'	INF	45.44'	INF	37.06'	INF
70'	39.27'	321.83'	38.04'	437.93'	31.99'	INF
50'	32.08'	113.25'	31.26'	124.89'	27.06'	329.05'
40'	27.65'	72.27'	27.04'	76.84'	23.84'	124.22'
30'	22.48'	45.08'	22.07'	46.81'	19.90'	60.97'
25'	19.55'	34.65'	19.25'	35.67'	17.57'	43.32'
20'	16.36'	25.72'	16.14'	26.28'	14.95'	30.21'
18'	15.00'	22.50'	14.82'	22.93'	13.81'	25.86'
16'	13.59'	19.46'	13.44'	19.77'	12.60'	21.91'
14'	12.12'	16.57'	12.00'	16.80'	11.33'	18.32'
13'	11.36'	15.19'	11.26'	15.38'	10.67'	16.64'
12'	10.59'	13.84'	10.50'	14.00'	9.99'	15.03'
11'	9.81'	12.53'	9.73'	12.65'	9.28'	13.49'
10'	9.01'	11.24'	8.94'	11.35'	8.56'	12.02'
9' 6"	8.60'	10.61'	8.54'	10.71'	8.19'	11.30'
9'	8.19'	9.99'	8.13'	10.07'	7.82'	10.60'
8' 6"	7.77'	9.38'	7.72'	9.45'	7.44'	9.91'
8'	7.35'	8.77'	7.31'	8.84'	7.06'	9.24'
7' 6"	6.93'	8.18'	6.89'	8.23'	6.67'	8.57'
7'	6.50'	7.58'	6.47'	7.63'	6.27'	7.93'
6' 6"	6.07'	7.00'	6.04'	7.04'	5.87'	7.29'
6'	5.63'	6.42'	5.60'	6.46'	5.46'	6.67'
5' 9"	5.41'	6.14'	5.39'	6.17'	5.25'	6.36'
5' 6"	5.19'	5.85'	5.17'	5.88'	5.04'	6.05'
5' 3"	4.97'	5.57'	4.95'	5.59'	4.83'	5.75'
5'	4.74'	5.29'	4.72'	5.31'	4.62'	5.45'
4' 9"	4.52'	5.01'	4.50'	5.03'	4.40'	5.16'
4' 6"	4.29'	4.73'	4.28'	4.75'	4.19'	4.86'
4' 3"	4.06'	4.46'	4.05'	4.47'	3.97'	4.57'
4'	3.83'	4.18'	3.82'	4.20'	3.75'	4.28'
3' 9"	3.60'	3.91'	3.59'	3.92'	3.53'	4.00'
3' 6"	3.37'	3.64'	3.36'	3.65'	3.31'	3.71'
3' 3"	3.14'	3.37'	3.13'	3.38'	3.09'	3.43'
3'	2.91'	3.10'	2.90'	3.11'	2.86'	3.15'
2' 9"	2.67'	2.83'	2.67'	2.84'	2.63'	2.88'
2' 6"	2.44'	2.57'	2.43'	2.57'	2.40'	2.61'

Depth of field tables

ARRI/ZEISS Master Anamorphic 2x MA 40/T1.9 T*XP

circle of confusion: 0.030 mm

Engraving	T-Stop					
	4		5.6		8	
ft	from	to	from	to	from	to
hyperfocal distance	41.71'		29.53'		20.92'	
INF	41.71'	INF	29.53'	INF	20.92'	INF
300'	36.53'	INF	26.79'	INF	19.45'	INF
150'	32.58'	INF	24.60'	INF	18.27'	INF
100'	29.40'	INF	22.75'	INF	17.23'	INF
70'	26.12'	INF	20.73'	INF	16.05'	INF
50'	22.73'	INF	18.55'	INF	14.71'	INF
40'	20.42'	971.46'	16.98'	INF	13.71'	INF
30'	17.46'	106.51'	14.88'	INF	12.31'	INF
25'	15.64'	62.20'	13.54'	162.14'	11.38'	INF
20'	13.53'	38.30'	11.94'	61.68'	10.23'	451.15'
18'	12.59'	31.56'	11.20'	45.89'	9.68'	128.09'
16'	11.58'	25.88'	10.39'	34.76'	9.07'	67.59'
14'	10.50'	21.01'	9.51'	26.50'	8.40'	42.05'
13'	9.93'	18.83'	9.04'	23.12'	8.03'	34.12'
12'	9.34'	16.79'	8.55'	20.12'	7.64'	27.96'
11'	8.72'	14.89'	8.03'	17.45'	7.22'	23.05'
10'	8.08'	13.11'	7.49'	15.05'	6.78'	19.04'
9' 6"	7.75'	12.26'	7.20'	13.94'	6.55'	17.29'
9'	7.42'	11.44'	6.91'	12.89'	6.31'	15.70'
8' 6"	7.08'	10.64'	6.62'	11.88'	6.06'	14.23'
8'	6.73'	9.87'	6.31'	10.92'	5.80'	12.87'
7' 6"	6.37'	9.12'	6.00'	10.01'	5.54'	11.62'
7'	6.01'	8.39'	5.67'	9.13'	5.26'	10.45'
6' 6"	5.64'	7.68'	5.34'	8.30'	4.98'	9.37'
6'	5.26'	6.99'	5.00'	7.50'	4.68'	8.36'
5' 9"	5.07'	6.65'	4.83'	7.11'	4.53'	7.88'
5' 6"	4.87'	6.32'	4.65'	6.73'	4.37'	7.42'
5' 3"	4.68'	5.99'	4.47'	6.36'	4.21'	6.97'
5'	4.48'	5.66'	4.29'	5.99'	4.05'	6.53'
4' 9"	4.28'	5.34'	4.11'	5.64'	3.89'	6.11'
4' 6"	4.07'	5.03'	3.92'	5.29'	3.72'	5.70'
4' 3"	3.87'	4.72'	3.73'	4.94'	3.55'	5.30'
4'	3.66'	4.41'	3.54'	4.61'	3.37'	4.92'
3' 9"	3.45'	4.11'	3.34'	4.28'	3.19'	4.54'
3' 6"	3.24'	3.81'	3.14'	3.95'	3.01'	4.18'
3' 3"	3.02'	3.51'	2.94'	3.64'	2.83'	3.82'
3'	2.81'	3.22'	2.73'	3.32'	2.64'	3.48'
2' 9"	2.59'	2.94'	2.53'	3.02'	2.44'	3.15'
2' 6"	2.37'	2.65'	2.31'	2.72'	2.24'	2.82'

Depth of field tables

ARRI/ZEISS Master Anamorphic 2x MA 40/T1.9 T*XP

circle of confusion: 0.030 mm

Engraving	T-Stop					
	11		16		22	
ft	from	to	from	to	from	to
hyperfocal distance	14.83'		10.53'		7.48'	
INF	14.83'	INF	10.53'	INF	7.48'	INF
300'	14.02'	INF	10.05'	INF	7.18'	INF
150'	13.40'	INF	9.73'	INF	7.01'	INF
100'	12.83'	INF	9.43'	INF	6.86'	INF
70'	12.17'	INF	9.07'	INF	6.66'	INF
50'	11.38'	INF	8.63'	INF	6.42'	INF
40'	10.78'	INF	8.27'	INF	6.23'	INF
30'	9.90'	INF	7.75'	INF	5.93'	INF
25'	9.29'	INF	7.37'	INF	5.70'	INF
20'	8.51'	INF	6.87'	INF	5.40'	INF
18'	8.13'	INF	6.62'	INF	5.25'	INF
16'	7.69'	INF	6.33'	INF	5.07'	INF
14'	7.20'	247.29'	6.00'	INF	4.85'	INF
13'	6.93'	104.30'	5.81'	INF	4.73'	INF
12'	6.64'	62.29'	5.60'	INF	4.59'	INF
11'	6.32'	42.20'	5.38'	INF	4.44'	INF
10'	5.98'	30.42'	5.13'	197.46'	4.27'	INF
9' 6"	5.80'	26.19'	5.00'	96.21'	4.18'	INF
9'	5.61'	22.69'	4.86'	61.29'	4.08'	INF
8' 6"	5.42'	19.73'	4.71'	43.60'	3.98'	INF
8'	5.21'	17.21'	4.55'	32.92'	3.86'	INF
7' 6"	5.00'	15.04'	4.39'	25.76'	3.75'	INF
7'	4.77'	13.14'	4.22'	20.64'	3.62'	106.81'
6' 6"	4.54'	11.47'	4.03'	16.78'	3.48'	48.67'
6'	4.29'	9.99'	3.84'	13.78'	3.34'	29.76'
5' 9"	4.16'	9.31'	3.73'	12.51'	3.26'	24.41'
5' 6"	4.03'	8.66'	3.63'	11.38'	3.18'	20.40'
5' 3"	3.89'	8.06'	3.52'	10.34'	3.10'	17.29'
5'	3.76'	7.48'	3.41'	9.41'	3.01'	14.81'
4' 9"	3.61'	6.93'	3.29'	8.55'	2.92'	12.78'
4' 6"	3.47'	6.40'	3.17'	7.76'	2.82'	11.09'
4' 3"	3.32'	5.90'	3.04'	7.04'	2.72'	9.67'
4'	3.17'	5.43'	2.92'	6.37'	2.62'	8.45'
3' 9"	3.01'	4.98'	2.78'	5.75'	2.51'	7.39'
3' 6"	2.85'	4.54'	2.64'	5.18'	2.40'	6.46'
3' 3"	2.68'	4.13'	2.50'	4.64'	2.28'	5.65'
3'	2.51'	3.73'	2.35'	4.14'	2.16'	4.92'
2' 9"	2.33'	3.35'	2.20'	3.68'	2.03'	4.27'
2' 6"	2.15'	2.98'	2.04'	3.24'	1.89'	3.69'

Depth of field tables

ARRI/ZEISS Master Anamorphic 2x MA 50/T1.9 T*XP

circle of confusion: 0.030 mm

Engraving	T-Stop					
	1.9		2		2.8	
ft	from	to	from	to	from	to
hyperfocal distance	136.79'		127.32'		90.08'	
INF	136.79'	INF	127.32'	INF	90.08'	INF
300'	93.91'	INF	89.34'	INF	69.21'	INF
150'	71.54'	INF	68.86'	INF	56.26'	INF
100'	57.78'	371.34'	56.02'	465.37'	47.39'	INF
70'	46.32'	143.19'	45.19'	155.28'	39.40'	313.45'
50'	36.64'	78.71'	35.92'	82.23'	32.17'	112.17'
40'	30.97'	56.46'	30.46'	58.25'	27.72'	71.82'
30'	24.62'	38.38'	24.30'	39.20'	22.53'	44.90'
25'	21.16'	30.55'	20.92'	31.07'	19.59'	34.54'
20'	17.46'	23.40'	17.30'	23.70'	16.39'	25.66'
18'	15.92'	20.70'	15.79'	20.94'	15.02'	22.45'
16'	14.34'	18.10'	14.23'	18.28'	13.60'	19.42'
14'	12.71'	15.58'	12.63'	15.71'	12.13'	16.55'
12'	11.04'	13.14'	10.98'	13.23'	10.60'	13.82'
11'	10.19'	11.95'	10.14'	12.03'	9.82'	12.51'
10'	9.33'	10.78'	9.28'	10.84'	9.01'	11.23'
9'	8.45'	9.62'	8.42'	9.67'	8.20'	9.98'
8'	7.57'	8.49'	7.54'	8.53'	7.36'	8.76'
7' 6"	7.12'	7.93'	7.09'	7.96'	6.93'	8.17'
7'	6.67'	7.37'	6.64'	7.40'	6.51'	7.58'
6' 6"	6.21'	6.82'	6.19'	6.84'	6.07'	6.99'
6'	5.75'	6.27'	5.74'	6.29'	5.63'	6.42'
5' 9"	5.52'	6.00'	5.51'	6.01'	5.41'	6.13'
5' 6"	5.29'	5.72'	5.28'	5.74'	5.19'	5.85'
5' 3"	5.06'	5.45'	5.05'	5.47'	4.97'	5.57'
5'	4.83'	5.18'	4.82'	5.20'	4.75'	5.28'
4' 9"	4.60'	4.92'	4.59'	4.93'	4.52'	5.01'
4' 6"	4.36'	4.65'	4.35'	4.66'	4.29'	4.73'
4' 3"	4.13'	4.38'	4.12'	4.39'	4.07'	4.45'
4'	3.89'	4.12'	3.88'	4.12'	3.84'	4.18'
3' 9"	3.65'	3.85'	3.65'	3.86'	3.61'	3.91'
3' 6"	3.42'	3.59'	3.41'	3.59'	3.38'	3.64'
3' 3"	3.18'	3.33'	3.17'	3.33'	3.14'	3.37'
3'	2.94'	3.06'	2.94'	3.07'	2.91'	3.10'
2' 9"	2.70'	2.80'	2.70'	2.81'	2.67'	2.83'
2' 6"	2.46'	2.54'	2.46'	2.55'	2.44'	2.57'

Depth of field tables

ARRI/ZEISS Master Anamorphic 2x MA 50/T1.9 T*XP

circle of confusion: 0.030 mm

Engraving	T-Stop					
	4		5.6		8	
ft	from	to	from	to	from	to
hyperfocal distance	63.74'		45.12'		31.95'	
INF	63.74'	INF	45.12'	INF	31.95'	INF
300'	52.49'	INF	39.12'	INF	28.76'	INF
150'	44.69'	INF	34.62'	INF	26.26'	INF
100'	38.91'	INF	31.05'	INF	24.15'	INF
70'	33.36'	INF	27.42'	INF	21.90'	INF
50'	28.03'	231.30'	23.71'	INF	19.47'	INF
40'	24.59'	107.11'	21.21'	351.10'	17.75'	INF
30'	20.42'	56.53'	18.03'	89.19'	15.48'	488.05'
25'	17.98'	41.03'	16.10'	55.86'	14.04'	114.29'
20'	15.24'	29.07'	13.88'	35.79'	12.32'	53.19'
18'	14.06'	25.02'	12.89'	29.84'	11.53'	41.01'
16'	12.81'	21.31'	11.83'	24.70'	10.68'	31.88'
14'	11.50'	17.89'	10.71'	20.22'	9.76'	24.79'
12'	10.12'	14.75'	9.50'	16.29'	8.74'	19.12'
11'	9.40'	13.26'	8.86'	14.49'	8.20'	16.69'
10'	8.66'	11.83'	8.21'	12.80'	7.64'	14.48'
9'	7.90'	10.45'	7.52'	11.20'	7.04'	12.46'
8'	7.12'	9.13'	6.81'	9.69'	6.42'	10.62'
7' 6"	6.72'	8.48'	6.45'	8.96'	6.09'	9.75'
7'	6.32'	7.84'	6.08'	8.26'	5.76'	8.92'
6' 6"	5.91'	7.22'	5.70'	7.57'	5.42'	8.12'
6'	5.50'	6.61'	5.31'	6.90'	5.07'	7.35'
5' 9"	5.29'	6.30'	5.12'	6.57'	4.89'	6.98'
5' 6"	5.07'	6.00'	4.92'	6.24'	4.71'	6.61'
5' 3"	4.86'	5.71'	4.72'	5.92'	4.53'	6.25'
5'	4.65'	5.41'	4.51'	5.60'	4.34'	5.90'
4' 9"	4.43'	5.12'	4.31'	5.29'	4.15'	5.55'
4' 6"	4.21'	4.83'	4.10'	4.98'	3.96'	5.21'
4' 3"	3.99'	4.54'	3.90'	4.68'	3.77'	4.88'
4'	3.77'	4.26'	3.69'	4.37'	3.57'	4.55'
3' 9"	3.55'	3.97'	3.47'	4.08'	3.37'	4.23'
3' 6"	3.33'	3.69'	3.26'	3.78'	3.17'	3.91'
3' 3"	3.10'	3.42'	3.04'	3.49'	2.96'	3.60'
3'	2.87'	3.14'	2.82'	3.20'	2.75'	3.29'
2' 9"	2.64'	2.87'	2.60'	2.92'	2.54'	2.99'
2' 6"	2.41'	2.60'	2.38'	2.64'	2.33'	2.70'

Depth of field tables

ARRI/ZEISS Master Anamorphic 2x MA 50/T1.9 T*XP

circle of confusion: 0.030 mm

Engraving	T-Stop					
	11		16		22	
ft	from	to	from	to	from	to
hyperfocal distance	22.64'		16.06'		11.40'	
INF	22.64'	INF	16.06'	INF	11.40'	INF
300'	20.92'	INF	15.10'	INF	10.84'	INF
150'	19.57'	INF	14.39'	INF	10.47'	INF
100'	18.38'	INF	13.73'	INF	10.12'	INF
70'	17.05'	INF	12.98'	INF	9.70'	INF
50'	15.54'	INF	12.09'	INF	9.20'	INF
40'	14.43'	INF	11.41'	INF	8.80'	INF
30'	12.89'	INF	10.43'	INF	8.21'	INF
25'	11.88'	INF	9.76'	INF	7.79'	INF
20'	10.63'	170.10'	8.90'	INF	7.23'	INF
18'	10.04'	87.15'	8.48'	INF	6.96'	INF
16'	9.39'	54.14'	8.02'	INF	6.64'	INF
14'	8.67'	36.41'	7.49'	108.08'	6.28'	INF
12'	7.86'	25.35'	6.88'	46.99'	5.85'	INF
11'	7.42'	21.24'	6.54'	34.56'	5.60'	306.41'
10'	6.96'	17.78'	6.18'	26.23'	5.33'	80.08'
9'	6.46'	14.83'	5.78'	20.27'	5.04'	42.09'
8'	5.93'	12.28'	5.36'	15.78'	4.71'	26.42'
7' 6"	5.66'	11.13'	5.13'	13.93'	4.54'	21.60'
7'	5.37'	10.06'	4.90'	12.28'	4.35'	17.87'
6' 6"	5.07'	9.05'	4.65'	10.81'	4.16'	14.90'
6'	4.76'	8.10'	4.39'	9.48'	3.95'	12.48'
5' 9"	4.61'	7.65'	4.26'	8.87'	3.84'	11.43'
5' 6"	4.45'	7.21'	4.12'	8.28'	3.73'	10.47'
5' 3"	4.28'	6.79'	3.98'	7.72'	3.61'	9.59'
5'	4.12'	6.37'	3.83'	7.19'	3.50'	8.78'
4' 9"	3.95'	5.97'	3.69'	6.68'	3.37'	8.02'
4' 6"	3.77'	5.58'	3.54'	6.19'	3.25'	7.33'
4' 3"	3.60'	5.19'	3.38'	5.72'	3.12'	6.68'
4'	3.42'	4.82'	3.22'	5.27'	2.98'	6.07'
3' 9"	3.23'	4.46'	3.06'	4.84'	2.84'	5.51'
3' 6"	3.05'	4.11'	2.89'	4.43'	2.70'	4.98'
3' 3"	2.86'	3.77'	2.72'	4.03'	2.55'	4.48'
3'	2.66'	3.43'	2.55'	3.65'	2.40'	4.01'
2' 9"	2.47'	3.11'	2.37'	3.28'	2.24'	3.57'
2' 6"	2.27'	2.79'	2.18'	2.93'	2.07'	3.16'

Depth of field tables

ARRI/ZEISS Master Anamorphic 2x MA 60/T1.9 T*XP

circle of confusion: 0.030 mm

Engraving	T-Stop					
	1.9		2		2.8	
ft	from	to	from	to	from	to
hyperfocal distance	192.59'		179.58'		127.04'	
INF	192.59'	INF	179.58'	INF	127.04'	INF
300'	117.27'	INF	112.31'	INF	89.19'	INF
150'	84.34'	677.55'	81.74'	909.56'	68.78'	INF
100'	65.84'	207.79'	64.25'	225.41'	55.97'	469.06'
70'	51.37'	109.86'	50.39'	114.59'	45.15'	155.66'
50'	39.72'	67.46'	39.14'	69.22'	35.90'	82.32'
40'	33.14'	50.43'	32.74'	51.41'	30.45'	58.29'
30'	25.98'	35.50'	25.73'	35.98'	24.29'	39.21'
25'	22.15'	28.70'	21.96'	29.01'	20.91'	31.08'
22'	19.76'	24.81'	19.62'	25.04'	18.77'	26.57'
20'	18.13'	22.30'	18.01'	22.48'	17.30'	23.70'
18'	16.48'	19.84'	16.38'	19.98'	15.79'	20.94'
16'	14.79'	17.43'	14.71'	17.55'	14.23'	18.28'
14'	13.06'	15.08'	13.00'	15.17'	12.63'	15.71'
13'	12.19'	13.93'	12.13'	14.00'	11.81'	14.46'
12'	11.31'	12.78'	11.26'	12.85'	10.98'	13.23'
11'	10.42'	11.65'	10.38'	11.71'	10.14'	12.02'
10'	9.52'	10.54'	9.48'	10.58'	9.28'	10.84'
9' 6"	9.06'	9.98'	9.03'	10.02'	8.85'	10.25'
9'	8.61'	9.43'	8.58'	9.46'	8.42'	9.67'
8' 6"	8.15'	8.88'	8.12'	8.91'	7.98'	9.10'
8'	7.69'	8.34'	7.67'	8.36'	7.54'	8.52'
7' 6"	7.23'	7.80'	7.21'	7.82'	7.09'	7.96'
7'	6.76'	7.26'	6.74'	7.28'	6.64'	7.40'
6' 6"	6.29'	6.72'	6.28'	6.74'	6.19'	6.84'
6'	5.82'	6.19'	5.81'	6.20'	5.74'	6.29'
5' 9"	5.59'	5.92'	5.58'	5.93'	5.51'	6.01'
5' 6"	5.35'	5.66'	5.34'	5.67'	5.28'	5.74'
5' 3"	5.12'	5.39'	5.11'	5.40'	5.05'	5.47'
5'	4.88'	5.13'	4.87'	5.14'	4.82'	5.20'
4' 9"	4.64'	4.87'	4.63'	4.87'	4.59'	4.93'
4' 6"	4.40'	4.60'	4.40'	4.61'	4.35'	4.66'
4' 3"	4.16'	4.34'	4.16'	4.35'	4.12'	4.39'
4'	3.92'	4.08'	3.92'	4.09'	3.88'	4.12'
3' 9"	3.68'	3.82'	3.68'	3.83'	3.65'	3.86'
3' 6"	3.44'	3.56'	3.44'	3.57'	3.41'	3.59'
3' 3"	3.20'	3.30'	3.20'	3.31'	3.17'	3.33'
3'	2.96'	3.04'	2.95'	3.05'	2.94'	3.07'

Depth of field tables

ARRI/ZEISS Master Anamorphic 2x MA 60/T1.9 T*XP

circle of confusion: 0.030 mm

Engraving	T-Stop					
	4		5.6		8	
ft	from	to	from	to	from	to
hyperfocal distance	89.89'		63.62'		45.04'	
INF	89.89'	INF	63.62'	INF	45.04'	INF
300'	69.08'	INF	52.38'	INF	39.04'	INF
150'	56.18'	INF	44.62'	INF	34.56'	INF
100'	47.33'	INF	38.86'	INF	31.00'	INF
70'	39.37'	315.66'	33.32'	INF	27.38'	INF
50'	32.15'	112.43'	28.01'	232.84'	23.69'	INF
40'	27.71'	71.91'	24.58'	107.41'	21.19'	355.68'
30'	22.52'	44.93'	20.41'	56.59'	18.02'	89.43'
25'	19.58'	34.56'	17.97'	41.06'	16.10'	55.94'
22'	17.70'	29.07'	16.37'	33.53'	14.80'	42.82'
20'	16.38'	25.67'	15.24'	29.08'	13.87'	35.82'
18'	15.02'	22.46'	14.06'	25.03'	12.89'	29.85'
16'	13.60'	19.42'	12.81'	21.31'	11.83'	24.71'
14'	12.13'	16.55'	11.50'	17.90'	10.71'	20.23'
13'	11.38'	15.17'	10.82'	16.29'	10.11'	18.19'
12'	10.61'	13.82'	10.12'	14.74'	9.50'	16.29'
11'	9.82'	12.51'	9.40'	13.26'	8.87'	14.49'
10'	9.02'	11.23'	8.66'	11.83'	8.21'	12.80'
9' 6"	8.61'	10.60'	8.29'	11.13'	7.87'	11.99'
9'	8.20'	9.98'	7.90'	10.45'	7.52'	11.20'
8' 6"	7.78'	9.37'	7.52'	9.78'	7.17'	10.43'
8'	7.36'	8.76'	7.12'	9.12'	6.81'	9.69'
7' 6"	6.94'	8.17'	6.73'	8.48'	6.45'	8.96'
7'	6.51'	7.58'	6.32'	7.84'	6.08'	8.25'
6' 6"	6.07'	6.99'	5.91'	7.22'	5.70'	7.56'
6'	5.64'	6.42'	5.50'	6.60'	5.31'	6.89'
5' 9"	5.42'	6.13'	5.29'	6.30'	5.12'	6.56'
5' 6"	5.19'	5.85'	5.08'	6.00'	4.92'	6.24'
5' 3"	4.97'	5.56'	4.86'	5.71'	4.72'	5.92'
5'	4.75'	5.28'	4.65'	5.41'	4.52'	5.60'
4' 9"	4.52'	5.00'	4.43'	5.12'	4.31'	5.29'
4' 6"	4.29'	4.73'	4.21'	4.83'	4.11'	4.98'
4' 3"	4.07'	4.45'	4.00'	4.54'	3.90'	4.67'
4'	3.84'	4.18'	3.77'	4.26'	3.69'	4.37'
3' 9"	3.61'	3.91'	3.55'	3.97'	3.48'	4.07'
3' 6"	3.38'	3.63'	3.33'	3.69'	3.26'	3.78'
3' 3"	3.14'	3.37'	3.10'	3.41'	3.04'	3.49'
3'	2.91'	3.10'	2.87'	3.14'	2.82'	3.20'

Depth of field tables

ARRI/ZEISS Master Anamorphic 2x MA 60/T1.9 T*XP

circle of confusion: 0.030 mm

Engraving	T-Stop					
	11		16		22	
ft	from	to	from	to	from	to
hyperfocal distance	31.91'		22.62'		16.05'	
INF	31.91'	INF	22.62'	INF	16.05'	INF
300'	28.70'	INF	20.88'	INF	15.07'	INF
150'	26.21'	INF	19.53'	INF	14.36'	INF
100'	24.11'	INF	18.35'	INF	13.71'	INF
70'	21.87'	INF	17.02'	INF	12.96'	INF
50'	19.45'	INF	15.52'	INF	12.07'	INF
40'	17.74'	INF	14.41'	INF	11.40'	INF
30'	15.47'	498.55'	12.88'	INF	10.42'	INF
25'	14.03'	114.76'	11.87'	INF	9.75'	INF
22'	13.04'	70.41'	11.15'	795.44'	9.26'	INF
20'	12.31'	53.26'	10.62'	171.16'	8.89'	INF
18'	11.53'	41.04'	10.03'	87.36'	8.48'	INF
16'	10.68'	31.89'	9.39'	54.19'	8.01'	INF
14'	9.75'	24.79'	8.67'	36.42'	7.48'	108.15'
13'	9.26'	21.80'	8.28'	30.30'	7.19'	67.53'
12'	8.75'	19.12'	7.86'	25.34'	6.88'	46.95'
11'	8.21'	16.68'	7.42'	21.23'	6.54'	34.52'
10'	7.64'	14.48'	6.96'	17.77'	6.18'	26.20'
9' 6"	7.35'	13.44'	6.71'	16.24'	5.99'	22.99'
9'	7.04'	12.46'	6.46'	14.82'	5.79'	20.23'
8' 6"	6.74'	11.52'	6.20'	13.50'	5.58'	17.85'
8'	6.42'	10.61'	5.94'	12.27'	5.36'	15.75'
7' 6"	6.10'	9.74'	5.66'	11.12'	5.14'	13.90'
7'	5.76'	8.91'	5.37'	10.05'	4.90'	12.26'
6' 6"	5.42'	8.11'	5.07'	9.04'	4.65'	10.79'
6'	5.07'	7.34'	4.77'	8.10'	4.39'	9.46'
5' 9"	4.89'	6.97'	4.61'	7.64'	4.26'	8.85'
5' 6"	4.71'	6.60'	4.45'	7.20'	4.12'	8.26'
5' 3"	4.53'	6.25'	4.28'	6.78'	3.98'	7.71'
5'	4.34'	5.89'	4.12'	6.36'	3.84'	7.17'
4' 9"	4.15'	5.55'	3.95'	5.96'	3.69'	6.66'
4' 6"	3.96'	5.21'	3.78'	5.57'	3.54'	6.18'
4' 3"	3.77'	4.87'	3.60'	5.19'	3.39'	5.71'
4'	3.57'	4.55'	3.42'	4.82'	3.23'	5.26'
3' 9"	3.37'	4.22'	3.24'	4.46'	3.06'	4.83'
3' 6"	3.17'	3.91'	3.05'	4.11'	2.90'	4.42'
3' 3"	2.97'	3.60'	2.86'	3.76'	2.73'	4.03'
3'	2.76'	3.29'	2.67'	3.43'	2.55'	3.64'

Depth of field tables

ARRI/ZEISS Master Anamorphic 2x MA 75/T1.9 T*XP

circle of confusion: 0.030 mm

Engraving	T-Stop					
	1.9		2		2.8	
ft	from	to	from	to	from	to
hyperfocal distance	292.22'		271.64'		192.15'	
INF	292.22'	INF	271.64'	INF	192.15'	INF
300'	148.03'	INF	142.55'	INF	117.10'	INF
150'	99.15'	307.95'	96.66'	334.67'	84.25'	682.91'
100'	74.54'	151.90'	73.12'	158.12'	65.80'	208.25'
70'	56.50'	91.97'	55.69'	94.22'	51.34'	109.97'
50'	42.72'	60.27'	42.25'	61.22'	39.71'	67.50'
40'	35.21'	46.31'	34.89'	46.87'	33.14'	50.45'
35'	31.28'	39.73'	31.03'	40.14'	29.63'	42.74'
30'	27.23'	33.40'	27.04'	33.69'	25.97'	35.51'
25'	23.05'	27.32'	22.91'	27.51'	22.14'	28.70'
22'	20.48'	23.77'	20.37'	23.92'	19.76'	24.81'
20'	18.73'	21.45'	18.64'	21.57'	18.13'	22.30'
18'	16.97'	19.17'	16.90'	19.26'	16.48'	19.84'
16'	15.18'	16.91'	15.12'	16.99'	14.79'	17.43'
14'	13.37'	14.69'	13.33'	14.75'	13.06'	15.08'
13'	12.46'	13.59'	12.42'	13.64'	12.19'	13.93'
12'	11.54'	12.50'	11.50'	12.54'	11.31'	12.78'
11'	10.61'	11.42'	10.58'	11.45'	10.42'	11.65'
10'	9.68'	10.35'	9.65'	10.37'	9.52'	10.54'
9' 6"	9.21'	9.81'	9.19'	9.84'	9.06'	9.98'
9'	8.74'	9.28'	8.72'	9.30'	8.61'	9.43'
8' 6"	8.27'	8.75'	8.25'	8.77'	8.15'	8.88'
8'	7.79'	8.22'	7.78'	8.24'	7.69'	8.34'
7' 6"	7.32'	7.69'	7.31'	7.71'	7.23'	7.80'
7'	6.84'	7.17'	6.83'	7.18'	6.76'	7.26'
6' 9"	6.60'	6.90'	6.59'	6.92'	6.53'	6.99'
6' 6"	6.36'	6.64'	6.35'	6.65'	6.30'	6.72'
6' 3"	6.12'	6.38'	6.12'	6.39'	6.06'	6.45'
6'	5.88'	6.12'	5.88'	6.13'	5.83'	6.19'
5' 9"	5.64'	5.86'	5.64'	5.87'	5.59'	5.92'
5' 6"	5.40'	5.60'	5.40'	5.61'	5.35'	5.66'
5' 3"	5.16'	5.34'	5.16'	5.35'	5.12'	5.39'
5'	4.92'	5.08'	4.91'	5.09'	4.88'	5.13'
4' 9"	4.68'	4.82'	4.67'	4.83'	4.64'	4.86'
4' 6"	4.44'	4.57'	4.43'	4.57'	4.40'	4.60'
4' 3"	4.19'	4.31'	4.19'	4.31'	4.16'	4.34'
4'	3.95'	4.05'	3.95'	4.06'	3.92'	4.08'
3' 9"	3.71'	3.80'	3.70'	3.80'	3.68'	3.82'
3' 6"	3.46'	3.54'	3.46'	3.54'	3.44'	3.56'
3' 3"	3.22'	3.28'	3.21'	3.29'	3.20'	3.30'
3'	2.97'	3.03'	2.97'	3.03'	2.96'	3.04'

Depth of field tables

ARRI/ZEISS Master Anamorphic 2x MA 75/T1.9 T*XP

circle of confusion: 0.030 mm

Engraving	T-Stop					
	4		5.6		8	
ft	from	to	from	to	from	to
hyperfocal distance	135.94'		96.20'		68.10'	
INF	135.94'	INF	96.20'	INF	68.10'	INF
300'	93.49'	INF	72.75'	INF	55.37'	INF
150'	71.31'	INF	58.58'	INF	46.77'	INF
100'	57.63'	377.53'	49.03'	INF	40.48'	INF
70'	46.23'	144.04'	40.53'	256.37'	34.52'	INF
50'	36.59'	78.95'	32.93'	103.85'	28.85'	187.48'
40'	30.94'	56.57'	28.28'	68.30'	25.22'	96.60'
35'	27.86'	47.05'	25.69'	54.88'	23.15'	71.75'
30'	24.61'	38.43'	22.90'	43.48'	20.86'	53.43'
25'	21.14'	30.58'	19.87'	33.69'	18.32'	39.36'
22'	18.96'	26.20'	17.93'	28.45'	16.66'	32.38'
20'	17.46'	23.41'	16.59'	25.19'	15.49'	28.22'
18'	15.92'	20.71'	15.19'	22.09'	14.27'	24.38'
16'	14.34'	18.10'	13.74'	19.14'	12.99'	20.84'
14'	12.71'	15.58'	12.25'	16.34'	11.64'	17.56'
13'	11.88'	14.35'	11.48'	14.99'	10.94'	16.01'
12'	11.04'	13.14'	10.69'	13.68'	10.23'	14.51'
11'	10.19'	11.95'	9.89'	12.39'	9.50'	13.07'
10'	9.33'	10.77'	9.08'	11.13'	8.74'	11.68'
9' 6"	8.89'	10.20'	8.66'	10.51'	8.36'	11.00'
9'	8.46'	9.62'	8.25'	9.90'	7.97'	10.33'
8' 6"	8.01'	9.05'	7.83'	9.30'	7.58'	9.68'
8'	7.57'	8.49'	7.40'	8.70'	7.18'	9.03'
7' 6"	7.12'	7.92'	6.97'	8.11'	6.78'	8.40'
7'	6.67'	7.37'	6.54'	7.53'	6.37'	7.77'
6' 9"	6.44'	7.09'	6.32'	7.24'	6.16'	7.47'
6' 6"	6.21'	6.81'	6.10'	6.95'	5.95'	7.16'
6' 3"	5.99'	6.54'	5.88'	6.67'	5.74'	6.86'
6'	5.76'	6.27'	5.66'	6.38'	5.53'	6.56'
5' 9"	5.53'	5.99'	5.44'	6.10'	5.32'	6.26'
5' 6"	5.30'	5.72'	5.21'	5.82'	5.11'	5.96'
5' 3"	5.06'	5.45'	4.99'	5.54'	4.89'	5.67'
5'	4.83'	5.18'	4.76'	5.26'	4.67'	5.38'
4' 9"	4.60'	4.91'	4.54'	4.98'	4.45'	5.09'
4' 6"	4.36'	4.65'	4.31'	4.71'	4.24'	4.80'
4' 3"	4.13'	4.38'	4.08'	4.44'	4.01'	4.52'
4'	3.89'	4.11'	3.85'	4.16'	3.79'	4.23'
3' 9"	3.66'	3.85'	3.62'	3.89'	3.57'	3.95'
3' 6"	3.42'	3.59'	3.39'	3.62'	3.34'	3.68'
3' 3"	3.18'	3.32'	3.15'	3.36'	3.11'	3.40'
3'	2.94'	3.06'	2.92'	3.09'	2.88'	3.13'

Depth of field tables

ARRI/ZEISS Master Anamorphic 2x MA 75/T1.9 T*XP

circle of confusion: 0.030 mm

Engraving	T-Stop					
	11		16		22	
ft	from	to	from	to	from	to
hyperfocal distance	48.22'		34.17'		24.23'	
INF	48.22'	INF	34.17'	INF	24.23'	INF
300'	41.39'	INF	30.50'	INF	22.23'	INF
150'	36.40'	INF	27.70'	INF	20.71'	INF
100'	32.48'	INF	25.38'	INF	19.39'	INF
70'	28.53'	INF	22.91'	INF	17.91'	INF
50'	24.55'	INF	20.27'	INF	16.27'	INF
40'	21.88'	233.39'	18.42'	INF	15.05'	INF
35'	20.30'	126.99'	17.29'	INF	14.29'	INF
30'	18.52'	78.98'	15.98'	244.03'	13.39'	INF
25'	16.49'	51.65'	14.45'	92.48'	12.30'	INF
22'	15.14'	40.25'	13.40'	61.32'	11.54'	236.20'
20'	14.17'	34.00'	12.64'	47.88'	10.97'	113.30'
18'	13.14'	28.57'	11.82'	37.76'	10.34'	69.26'
16'	12.05'	23.82'	10.93'	29.87'	9.66'	46.61'
14'	10.88'	19.63'	9.96'	23.55'	8.90'	32.82'
13'	10.27'	17.71'	9.45'	20.83'	8.49'	27.76'
12'	9.64'	15.89'	8.91'	18.36'	8.05'	23.53'
11'	8.99'	14.18'	8.35'	16.11'	7.60'	19.94'
10'	8.31'	12.55'	7.77'	14.04'	7.11'	16.85'
9' 6"	7.96'	11.77'	7.46'	13.06'	6.86'	15.47'
9'	7.61'	11.01'	7.15'	12.13'	6.59'	14.17'
8' 6"	7.25'	10.27'	6.84'	11.23'	6.32'	12.96'
8'	6.89'	9.54'	6.51'	10.37'	6.05'	11.82'
7' 6"	6.52'	8.84'	6.18'	9.54'	5.76'	10.75'
7'	6.14'	8.15'	5.84'	8.74'	5.46'	9.74'
6' 9"	5.94'	7.81'	5.66'	8.35'	5.31'	9.26'
6' 6"	5.75'	7.47'	5.49'	7.97'	5.16'	8.79'
6' 3"	5.56'	7.14'	5.31'	7.59'	5.00'	8.34'
6'	5.36'	6.82'	5.13'	7.23'	4.84'	7.89'
5' 9"	5.16'	6.50'	4.95'	6.86'	4.68'	7.46'
5' 6"	4.96'	6.18'	4.76'	6.51'	4.51'	7.04'
5' 3"	4.75'	5.86'	4.58'	6.16'	4.34'	6.63'
5'	4.55'	5.55'	4.39'	5.82'	4.17'	6.24'
4' 9"	4.34'	5.24'	4.19'	5.48'	4.00'	5.85'
4' 6"	4.13'	4.94'	4.00'	5.15'	3.82'	5.47'
4' 3"	3.92'	4.64'	3.80'	4.82'	3.64'	5.10'
4'	3.71'	4.34'	3.60'	4.50'	3.46'	4.74'
3' 9"	3.50'	4.05'	3.40'	4.18'	3.27'	4.39'
3' 6"	3.28'	3.76'	3.19'	3.87'	3.08'	4.05'
3' 3"	3.06'	3.47'	2.99'	3.57'	2.89'	3.72'
3'	2.84'	3.18'	2.78'	3.27'	2.69'	3.39'

Depth of field tables

ARRI/ZEISS Master Anamorphic 2x MA 100/T1.9 T*XP

circle of confusion: 0.030 mm

Engraving	T-Stop					
	1.9		2		2.8	
ft	from	to	from	to	from	to
hyperfocal distance	495.42'		461.44'		326.39'	
INF	495.42'	INF	461.44'	INF	326.39'	INF
300'	186.88'	760.04'	181.83'	856.86'	156.33'	INF
150'	115.18'	215.00'	113.24'	222.09'	102.81'	277.28'
100'	83.24'	125.21'	82.23'	127.58'	76.59'	144.03'
70'	61.36'	81.46'	60.81'	82.46'	57.68'	89.02'
50'	45.44'	55.58'	45.14'	56.04'	43.39'	58.99'
40'	37.03'	43.48'	36.83'	43.77'	35.66'	45.54'
35'	32.71'	37.64'	32.55'	37.85'	31.64'	39.17'
30'	28.30'	31.91'	28.19'	32.06'	27.50'	33.00'
25'	23.81'	26.31'	23.73'	26.41'	23.24'	27.05'
22'	21.08'	23.01'	21.01'	23.09'	20.63'	23.57'
20'	19.24'	20.83'	19.18'	20.89'	18.86'	21.28'
18'	17.38'	18.67'	17.34'	18.72'	17.08'	19.03'
16'	15.51'	16.52'	15.47'	16.56'	15.27'	16.81'
14'	13.62'	14.40'	13.60'	14.43'	13.44'	14.61'
13'	12.68'	13.34'	12.65'	13.37'	12.51'	13.53'
12'	11.72'	12.29'	11.70'	12.31'	11.59'	12.45'
11'	10.77'	11.24'	10.75'	11.26'	10.65'	11.37'
10'	9.81'	10.20'	9.80'	10.21'	9.71'	10.31'
9' 6"	9.33'	9.68'	9.32'	9.69'	9.24'	9.78'
9'	8.85'	9.16'	8.83'	9.17'	8.77'	9.25'
8' 6"	8.36'	8.64'	8.35'	8.65'	8.29'	8.72'
8'	7.88'	8.13'	7.87'	8.14'	7.82'	8.19'
7' 6"	7.39'	7.61'	7.39'	7.62'	7.34'	7.67'
7' 3"	7.15'	7.35'	7.14'	7.36'	7.10'	7.41'
7'	6.91'	7.10'	6.90'	7.10'	6.86'	7.15'
6' 9"	6.66'	6.84'	6.66'	6.85'	6.62'	6.89'
6' 6"	6.42'	6.58'	6.41'	6.59'	6.38'	6.63'
6' 3"	6.18'	6.33'	6.17'	6.33'	6.14'	6.37'
6'	5.93'	6.07'	5.93'	6.08'	5.90'	6.11'
5' 9"	5.69'	5.81'	5.68'	5.82'	5.66'	5.85'
5' 6"	5.44'	5.56'	5.44'	5.56'	5.41'	5.59'
5' 3"	5.20'	5.30'	5.20'	5.31'	5.17'	5.33'
5'	4.95'	5.05'	4.95'	5.05'	4.93'	5.07'
4' 9"	4.71'	4.79'	4.71'	4.80'	4.69'	4.82'
4' 6"	4.46'	4.54'	4.46'	4.54'	4.44'	4.56'
4' 3"	4.22'	4.28'	4.21'	4.29'	4.20'	4.30'
4'	3.97'	4.03'	3.97'	4.03'	3.96'	4.05'
3' 9"	3.72'	3.78'	3.72'	3.78'	3.71'	3.79'
3' 6"	3.48'	3.52'	3.48'	3.52'	3.47'	3.53'
3' 3"	3.23'	3.27'	3.23'	3.27'	3.22'	3.28'

Depth of field tables

ARRI/ZEISS Master Anamorphic 2x MA 100/T1.9 T*XP

circle of confusion: 0.030 mm

Engraving	T-Stop					
	4		5.6		8	
ft	from	to	from	to	from	to
hyperfocal distance	230.89'		163.36'		115.61'	
INF	230.89'	INF	163.36'	INF	115.61'	INF
300'	130.45'	INF	105.70'	INF	83.34'	INF
150'	90.96'	427.56'	78.20'	INF	65.26'	INF
100'	69.82'	176.15'	62.06'	257.32'	53.63'	738.63'
70'	53.76'	100.31'	49.04'	122.24'	43.63'	176.94'
50'	41.14'	63.73'	38.32'	71.91'	34.94'	87.86'
40'	34.13'	48.31'	32.17'	52.86'	29.76'	60.99'
35'	30.43'	41.20'	28.86'	44.45'	26.91'	50.06'
30'	26.58'	34.43'	25.38'	36.68'	23.86'	40.40'
25'	22.58'	28.00'	21.71'	29.46'	20.59'	31.81'
22'	20.11'	24.28'	19.42'	25.37'	18.52'	27.09'
20'	18.43'	21.87'	17.85'	22.74'	17.09'	24.12'
18'	16.72'	19.49'	16.24'	20.19'	15.61'	21.26'
16'	14.98'	17.17'	14.60'	17.70'	14.09'	18.52'
14'	13.22'	14.88'	12.92'	15.28'	12.52'	15.88'
13'	12.32'	13.76'	12.06'	14.10'	11.71'	14.61'
12'	11.42'	12.64'	11.20'	12.93'	10.90'	13.35'
11'	10.51'	11.53'	10.32'	11.77'	10.07'	12.12'
10'	9.60'	10.44'	9.44'	10.63'	9.23'	10.92'
9' 6"	9.14'	9.89'	8.99'	10.07'	8.80'	10.32'
9'	8.67'	9.35'	8.55'	9.51'	8.37'	9.73'
8' 6"	8.21'	8.81'	8.09'	8.95'	7.94'	9.15'
8'	7.74'	8.28'	7.64'	8.40'	7.50'	8.57'
7' 6"	7.27'	7.74'	7.18'	7.85'	7.06'	8.00'
7' 3"	7.04'	7.47'	6.96'	7.57'	6.84'	7.71'
7'	6.80'	7.21'	6.73'	7.30'	6.62'	7.43'
6' 9"	6.57'	6.94'	6.49'	7.03'	6.39'	7.15'
6' 6"	6.33'	6.68'	6.26'	6.76'	6.17'	6.87'
6' 3"	6.09'	6.42'	6.03'	6.49'	5.95'	6.59'
6'	5.86'	6.15'	5.80'	6.22'	5.72'	6.31'
5' 9"	5.62'	5.89'	5.57'	5.95'	5.49'	6.03'
5' 6"	5.38'	5.63'	5.33'	5.68'	5.26'	5.76'
5' 3"	5.14'	5.37'	5.10'	5.41'	5.04'	5.48'
5'	4.90'	5.10'	4.86'	5.15'	4.81'	5.21'
4' 9"	4.66'	4.84'	4.63'	4.88'	4.58'	4.94'
4' 6"	4.42'	4.58'	4.39'	4.62'	4.34'	4.67'
4' 3"	4.18'	4.32'	4.15'	4.36'	4.11'	4.40'
4'	3.94'	4.07'	3.91'	4.09'	3.88'	4.13'
3' 9"	3.70'	3.81'	3.67'	3.83'	3.64'	3.87'
3' 6"	3.45'	3.55'	3.43'	3.57'	3.41'	3.60'
3' 3"	3.21'	3.29'	3.19'	3.31'	3.17'	3.34'

Depth of field tables

ARRI/ZEISS Master Anamorphic 2x MA 100/T1.9 T*XP

circle of confusion: 0.030 mm

Engraving	T-Stop					
	11		16		22	
ft	from	to	from	to	from	to
hyperfocal distance	81.84'		57.97'		41.09'	
INF	81.84'	INF	57.97'	INF	41.09'	INF
300'	64.15'	INF	48.39'	INF	35.92'	INF
150'	52.89'	INF	41.71'	INF	32.10'	INF
100'	44.99'	INF	36.64'	INF	29.02'	INF
70'	37.74'	481.82'	31.69'	INF	25.84'	INF
50'	31.07'	128.00'	26.86'	361.71'	22.54'	INF
40'	26.91'	77.93'	23.69'	128.32'	20.27'	1501.99'
35'	24.56'	60.91'	21.85'	87.84'	18.91'	234.41'
30'	21.99'	47.17'	19.81'	61.83'	17.36'	110.30'
25'	19.19'	35.85'	17.51'	43.71'	15.57'	63.35'
22'	17.38'	29.97'	15.99'	35.26'	14.36'	46.98'
20'	16.11'	26.36'	14.91'	30.36'	13.49'	38.66'
18'	14.79'	22.98'	13.78'	25.96'	12.56'	31.78'
16'	13.42'	19.81'	12.58'	21.98'	11.56'	26.00'
14'	11.99'	16.82'	11.32'	18.35'	10.48'	21.07'
13'	11.25'	15.39'	10.66'	16.66'	9.92'	18.87'
12'	10.50'	14.01'	9.98'	15.05'	9.33'	16.82'
11'	9.73'	12.66'	9.28'	13.50'	8.72'	14.90'
10'	8.94'	11.35'	8.56'	12.02'	8.08'	13.11'
9' 6"	8.54'	10.70'	8.20'	11.30'	7.76'	12.26'
9'	8.14'	10.07'	7.82'	10.59'	7.42'	11.43'
8' 6"	7.73'	9.45'	7.45'	9.90'	7.08'	10.63'
8'	7.31'	8.83'	7.06'	9.23'	6.73'	9.86'
7' 6"	6.89'	8.22'	6.67'	8.57'	6.38'	9.10'
7' 3"	6.68'	7.92'	6.47'	8.24'	6.20'	8.73'
7'	6.47'	7.62'	6.27'	7.92'	6.02'	8.37'
6' 9"	6.26'	7.33'	6.07'	7.60'	5.83'	8.01'
6' 6"	6.04'	7.03'	5.87'	7.28'	5.65'	7.66'
6' 3"	5.83'	6.74'	5.67'	6.97'	5.46'	7.31'
6'	5.61'	6.45'	5.46'	6.66'	5.27'	6.97'
5' 9"	5.39'	6.16'	5.26'	6.35'	5.08'	6.63'
5' 6"	5.17'	5.87'	5.05'	6.04'	4.88'	6.30'
5' 3"	4.95'	5.59'	4.84'	5.74'	4.68'	5.97'
5'	4.73'	5.30'	4.63'	5.44'	4.49'	5.65'
4' 9"	4.51'	5.02'	4.41'	5.15'	4.29'	5.33'
4' 6"	4.28'	4.74'	4.20'	4.85'	4.08'	5.01'
4' 3"	4.06'	4.47'	3.98'	4.56'	3.88'	4.70'
4'	3.83'	4.19'	3.76'	4.27'	3.67'	4.40'
3' 9"	3.60'	3.91'	3.54'	3.99'	3.46'	4.09'
3' 6"	3.37'	3.64'	3.32'	3.70'	3.25'	3.80'
3' 3"	3.14'	3.37'	3.09'	3.42'	3.03'	3.50'

Depth of field tables

ARRI/ZEISS Master Anamorphic 2x MA 135/T1.9 T*XP

circle of confusion: 0.030 mm

Engraving	T-Stop					
	1.9		2		2.8	
ft	from	to	from	to	from	to
hyperfocal distance	945.02'		882.57'		624.20'	
INF	945.02'	INF	882.57'	INF	624.20'	INF
300'	227.77'	439.33'	223.95'	454.26'	202.67'	577.20'
150'	129.50'	178.22'	128.26'	180.62'	120.99'	197.31'
100'	90.47'	111.78'	89.86'	112.72'	86.24'	118.99'
70'	65.20'	75.56'	64.88'	75.99'	62.98'	78.79'
50'	47.51'	52.77'	47.34'	52.98'	46.32'	54.32'
40'	38.39'	41.75'	38.28'	41.88'	37.62'	42.71'
30'	29.09'	30.97'	29.03'	31.04'	28.64'	31.49'
25'	24.37'	25.67'	24.32'	25.72'	24.05'	26.03'
22'	21.51'	22.51'	21.48'	22.55'	21.27'	22.79'
20'	19.59'	20.42'	19.57'	20.45'	19.39'	20.65'
18'	17.67'	18.34'	17.65'	18.37'	17.51'	18.52'
16'	15.74'	16.27'	15.72'	16.29'	15.61'	16.41'
14'	13.80'	14.20'	13.79'	14.22'	13.70'	14.31'
13'	12.83'	13.18'	12.82'	13.19'	12.74'	13.27'
12'	11.86'	12.15'	11.85'	12.16'	11.78'	12.23'
11'	10.88'	11.12'	10.87'	11.13'	10.82'	11.19'
10'	9.90'	10.10'	9.89'	10.11'	9.85'	10.16'
9' 6"	9.41'	9.59'	9.40'	9.60'	9.36'	9.64'
9'	8.92'	9.08'	8.91'	9.09'	8.88'	9.13'
8' 6"	8.43'	8.57'	8.42'	8.58'	8.39'	8.61'
8'	7.94'	8.07'	7.93'	8.07'	7.90'	8.10'
7' 6"	7.44'	7.56'	7.44'	7.56'	7.42'	7.59'
7'	6.95'	7.05'	6.95'	7.05'	6.93'	7.07'
6' 9"	6.71'	6.80'	6.70'	6.80'	6.68'	6.82'
6' 6"	6.46'	6.54'	6.46'	6.55'	6.44'	6.56'
6' 3"	6.21'	6.29'	6.21'	6.29'	6.19'	6.31'
6'	5.97'	6.04'	5.96'	6.04'	5.95'	6.05'
5' 9"	5.72'	5.78'	5.72'	5.79'	5.70'	5.80'
5' 6"	5.47'	5.53'	5.47'	5.53'	5.46'	5.55'
5' 3"	5.22'	5.28'	5.22'	5.28'	5.21'	5.29'
5'	4.98'	5.02'	4.97'	5.03'	4.96'	5.04'
4' 9"	4.73'	4.77'	4.73'	4.77'	4.72'	4.78'
4' 6"	4.48'	4.52'	4.48'	4.52'	4.47'	4.53'
4' 3"	4.23'	4.27'	4.23'	4.27'	4.22'	4.28'
4'	3.99'	4.02'	3.98'	4.02'	3.98'	4.02'

Depth of field tables

ARRI/ZEISS Master Anamorphic 2x MA 135/T1.9 T*XP

circle of confusion: 0.030 mm

Engraving	T-Stop					
	4		5.6		8	
ft	from	to	from	to	from	to
hyperfocal distance	441.51'		312.32'		220.98'	
INF	441.51'	INF	312.32'	INF	220.98'	INF
300'	178.66'	935.07'	153.02'	7593.20'	127.21'	INF
150'	112.02'	226.96'	101.38'	288.20'	89.38'	466.08'
100'	81.59'	129.15'	75.80'	146.89'	68.90'	182.30'
70'	60.47'	83.11'	57.24'	90.09'	53.22'	102.25'
50'	44.95'	56.33'	43.14'	59.45'	40.83'	64.49'
40'	36.71'	43.94'	35.50'	45.81'	33.92'	48.74'
30'	28.12'	32.16'	27.40'	33.14'	26.45'	34.64'
25'	23.68'	26.47'	23.18'	27.14'	22.50'	28.13'
22'	20.98'	23.13'	20.58'	23.63'	20.04'	24.38'
20'	19.15'	20.93'	18.82'	21.34'	18.37'	21.95'
18'	17.31'	18.75'	17.04'	19.07'	16.67'	19.56'
16'	15.46'	16.59'	15.24'	16.84'	14.95'	17.21'
14'	13.58'	14.44'	13.42'	14.64'	13.19'	14.92'
13'	12.64'	13.38'	12.50'	13.55'	12.30'	13.79'
12'	11.69'	12.32'	11.57'	12.46'	11.40'	12.66'
11'	10.74'	11.27'	10.64'	11.39'	10.50'	11.55'
10'	9.79'	10.22'	9.70'	10.32'	9.59'	10.45'
9' 6"	9.31'	9.70'	9.23'	9.78'	9.13'	9.91'
9'	8.83'	9.18'	8.76'	9.25'	8.66'	9.36'
8' 6"	8.35'	8.66'	8.29'	8.73'	8.20'	8.82'
8'	7.87'	8.14'	7.81'	8.20'	7.74'	8.28'
7' 6"	7.38'	7.62'	7.33'	7.67'	7.27'	7.75'
7'	6.90'	7.11'	6.86'	7.15'	6.80'	7.22'
6' 9"	6.66'	6.85'	6.62'	6.89'	6.56'	6.95'
6' 6"	6.41'	6.59'	6.38'	6.63'	6.33'	6.68'
6' 3"	6.17'	6.33'	6.14'	6.37'	6.09'	6.42'
6'	5.93'	6.08'	5.90'	6.11'	5.85'	6.16'
5' 9"	5.68'	5.82'	5.65'	5.85'	5.62'	5.89'
5' 6"	5.44'	5.56'	5.41'	5.59'	5.38'	5.63'
5' 3"	5.19'	5.31'	5.17'	5.33'	5.14'	5.37'
5'	4.95'	5.05'	4.93'	5.07'	4.90'	5.11'
4' 9"	4.70'	4.80'	4.69'	4.82'	4.66'	4.85'
4' 6"	4.46'	4.54'	4.44'	4.56'	4.42'	4.58'
4' 3"	4.21'	4.29'	4.20'	4.30'	4.18'	4.33'
4'	3.97'	4.03'	3.96'	4.05'	3.94'	4.07'

Depth of field tables

ARRI/ZEISS Master Anamorphic 2x MA 135/T1.9 T*XP

circle of confusion: 0.030 mm

Engraving	T-Stop					
	11		16		22	
ft	from	to	from	to	from	to
hyperfocal distance	156.38'		110.71'		78.41'	
INF	156.38'	INF	110.71'	INF	78.41'	INF
300'	102.71'	INF	80.72'	INF	61.96'	INF
150'	76.57'	3664.87'	63.66'	INF	51.40'	INF
100'	61.03'	276.58'	52.55'	1029.67'	43.92'	INF
70'	48.41'	126.37'	42.92'	189.61'	37.00'	648.77'
50'	37.94'	73.29'	34.50'	90.82'	30.57'	137.21'
40'	31.91'	53.60'	29.44'	62.38'	26.54'	81.19'
30'	25.22'	37.02'	23.66'	40.99'	21.75'	48.32'
25'	21.60'	29.67'	20.45'	32.16'	19.01'	36.49'
22'	19.33'	25.53'	18.40'	27.35'	17.24'	30.41'
20'	17.77'	22.87'	16.99'	24.31'	15.99'	26.70'
18'	16.18'	20.28'	15.53'	21.41'	14.69'	23.23'
16'	14.55'	17.77'	14.02'	18.63'	13.34'	19.99'
14'	12.88'	15.33'	12.47'	15.96'	11.93'	16.95'
13'	12.03'	14.14'	11.67'	14.67'	11.20'	15.50'
12'	11.17'	12.96'	10.86'	13.41'	10.45'	14.09'
11'	10.30'	11.80'	10.04'	12.17'	9.69'	12.72'
10'	9.42'	10.65'	9.20'	10.95'	8.91'	11.40'
9' 6"	8.98'	10.09'	8.78'	10.35'	8.51'	10.75'
9'	8.53'	9.52'	8.35'	9.76'	8.11'	10.11'
8' 6"	8.08'	8.96'	7.92'	9.17'	7.70'	9.48'
8'	7.63'	8.41'	7.49'	8.59'	7.29'	8.86'
7' 6"	7.18'	7.86'	7.05'	8.01'	6.88'	8.25'
7'	6.72'	7.31'	6.61'	7.44'	6.46'	7.64'
6' 9"	6.49'	7.04'	6.39'	7.16'	6.25'	7.34'
6' 6"	6.26'	6.76'	6.16'	6.88'	6.03'	7.05'
6' 3"	6.03'	6.49'	5.94'	6.60'	5.82'	6.75'
6'	5.79'	6.22'	5.71'	6.32'	5.60'	6.46'
5' 9"	5.56'	5.95'	5.49'	6.04'	5.38'	6.17'
5' 6"	5.33'	5.68'	5.26'	5.76'	5.17'	5.88'
5' 3"	5.09'	5.42'	5.03'	5.49'	4.95'	5.60'
5'	4.86'	5.15'	4.80'	5.22'	4.72'	5.31'
4' 9"	4.62'	4.89'	4.57'	4.94'	4.50'	5.03'
4' 6"	4.39'	4.62'	4.34'	4.67'	4.28'	4.75'
4' 3"	4.15'	4.36'	4.11'	4.40'	4.05'	4.47'
4'	3.91'	4.09'	3.88'	4.13'	3.83'	4.19'

Depth of field tables

ARRI/ZEISS Master Anamorphic 2x MA 180/T2.8 T*XP

circle of confusion: 0.030 mm

Engraving	T-Stop					
	2.8		4		5.6	
ft	from	to	from	to	from	to
hyperfocal distance	1139.73'		784.07'		554.60'	
INF	1139.73'	INF	784.07'	INF	554.60'	INF
300'	237.56'	406.97'	217.05'	485.56'	194.75'	652.81'
150'	132.61'	172.64'	125.98'	185.35'	118.14'	205.39'
100'	91.97'	109.56'	88.74'	114.53'	84.79'	121.87'
70'	65.98'	74.54'	64.30'	76.80'	62.21'	80.03'
50'	47.92'	52.27'	47.03'	53.37'	45.91'	54.90'
40'	38.66'	41.43'	38.08'	42.12'	37.34'	43.06'
30'	29.25'	30.80'	28.92'	31.17'	28.49'	31.68'
25'	24.48'	25.55'	24.25'	25.80'	23.95'	26.15'
22'	21.59'	22.42'	21.42'	22.62'	21.18'	22.88'
20'	19.67'	20.35'	19.52'	20.51'	19.32'	20.73'
18'	17.73'	18.28'	17.61'	18.41'	17.45'	18.58'
16'	15.79'	16.22'	15.69'	16.32'	15.57'	16.46'
14'	13.84'	14.17'	13.76'	14.24'	13.67'	14.35'
13'	12.86'	13.14'	12.80'	13.21'	12.72'	13.30'
12'	11.88'	12.12'	11.83'	12.18'	11.76'	12.25'
11'	10.90'	11.10'	10.86'	11.15'	10.80'	11.21'
10'	9.92'	10.08'	9.88'	10.12'	9.83'	10.17'
9' 6"	9.43'	9.58'	9.39'	9.61'	9.35'	9.66'
9'	8.93'	9.07'	8.90'	9.10'	8.87'	9.14'
8' 6"	8.44'	8.56'	8.42'	8.59'	8.38'	8.62'
8'	7.95'	8.05'	7.93'	8.08'	7.89'	8.11'
7' 6"	7.46'	7.55'	7.43'	7.57'	7.41'	7.60'
7'	6.96'	7.04'	6.94'	7.06'	6.92'	7.08'
6' 9"	6.71'	6.79'	6.70'	6.80'	6.68'	6.83'
6' 6"	6.47'	6.53'	6.45'	6.55'	6.43'	6.57'
6' 3"	6.22'	6.28'	6.21'	6.30'	6.19'	6.32'
6'	5.97'	6.03'	5.96'	6.04'	5.94'	6.06'
5' 9"	5.72'	5.78'	5.71'	5.79'	5.70'	5.80'
5' 6"	5.48'	5.52'	5.47'	5.54'	5.45'	5.55'
5' 3"	5.23'	5.27'	5.22'	5.28'	5.21'	5.30'
5'	4.98'	5.02'	4.97'	5.03'	4.96'	5.04'

Depth of field tables

ARRI/ZEISS Master Anamorphic 2x MA 180/T2.8 T*XP

circle of confusion: 0.030 mm

Engraving	T-Stop					
	8		11		16	
ft	from	to	from	to	from	to
hyperfocal distance	392.33'		277.59'		196.46'	
INF	392.33'	INF	277.59'	INF	196.46'	INF
300'	170.04'	1272.83'	144.17'	INF	118.64'	INF
150'	108.59'	242.48'	97.44'	325.65'	85.09'	632.37'
100'	79.76'	134.01'	73.59'	155.98'	66.33'	203.06'
70'	59.46'	85.07'	55.97'	93.41'	51.69'	108.42'
50'	44.40'	57.22'	42.43'	60.86'	39.93'	66.87'
40'	36.34'	44.47'	35.02'	46.64'	33.30'	50.08'
30'	27.91'	32.44'	27.12'	33.56'	26.08'	35.30'
25'	23.53'	26.66'	22.98'	27.42'	22.23'	28.56'
22'	20.86'	23.27'	20.42'	23.84'	19.83'	24.70'
20'	19.06'	21.04'	18.69'	21.51'	18.20'	22.20'
18'	17.23'	18.84'	16.94'	19.21'	16.53'	19.76'
16'	15.39'	16.66'	15.16'	16.94'	14.83'	17.37'
14'	13.54'	14.50'	13.35'	14.71'	13.10'	15.03'
13'	12.60'	13.43'	12.44'	13.61'	12.23'	13.88'
12'	11.66'	12.36'	11.53'	12.52'	11.34'	12.74'
11'	10.72'	11.30'	10.60'	11.43'	10.45'	11.62'
10'	9.77'	10.25'	9.67'	10.35'	9.54'	10.51'
9' 6"	9.29'	9.72'	9.20'	9.82'	9.09'	9.95'
9'	8.81'	9.20'	8.74'	9.28'	8.63'	9.40'
8' 6"	8.33'	8.68'	8.26'	8.75'	8.17'	8.86'
8'	7.85'	8.15'	7.79'	8.22'	7.71'	8.32'
7' 6"	7.37'	7.64'	7.32'	7.69'	7.24'	7.77'
7'	6.89'	7.12'	6.84'	7.17'	6.78'	7.24'
6' 9"	6.65'	6.86'	6.60'	6.90'	6.54'	6.97'
6' 6"	6.40'	6.60'	6.36'	6.64'	6.31'	6.70'
6' 3"	6.16'	6.34'	6.13'	6.38'	6.07'	6.44'
6'	5.92'	6.08'	5.89'	6.12'	5.84'	6.17'
5' 9"	5.68'	5.83'	5.65'	5.86'	5.60'	5.91'
5' 6"	5.43'	5.57'	5.40'	5.60'	5.37'	5.64'
5' 3"	5.19'	5.31'	5.16'	5.34'	5.13'	5.38'
5'	4.94'	5.06'	4.92'	5.08'	4.89'	5.12'

Depth of field tables

ARRI/ZEISS Master Anamorphic 2x MA 180/T2.8 T*XP

circle of confusion: 0.030 mm

Engraving	T-Stop	
	22	
ft	from	to
hyperfocal distance	139.09'	
INF	139.09'	INF
300'	94.88'	INF
150'	72.16'	INF
100'	58.22'	354.30'
70'	46.63'	140.32'
50'	36.85'	77.73'
40'	31.14'	55.91'
30'	24.75'	38.09'
25'	21.25'	30.35'
22'	19.06'	26.02'
20'	17.54'	23.26'
18'	15.99'	20.59'
16'	14.40'	18.00'
14'	12.76'	15.50'
13'	11.93'	14.28'
12'	11.09'	13.08'
11'	10.23'	11.89'
10'	9.36'	10.73'
9' 6"	8.93'	10.15'
9'	8.49'	9.58'
8' 6"	8.04'	9.02'
8'	7.59'	8.45'
7' 6"	7.14'	7.89'
7'	6.69'	7.34'
6' 9"	6.46'	7.06'
6' 6"	6.23'	6.79'
6' 3"	6.01'	6.52'
6'	5.77'	6.24'
5' 9"	5.54'	5.97'
5' 6"	5.31'	5.70'
5' 3"	5.08'	5.43'
5'	4.85'	5.16'